

How can you expand your serial port count in PC?

RAYON can offer you expert method to expand your serial port count in PC.

1) insert ISA & PCI add-on card.

Support upto 64 serial ports per card.

Need ISA & PCI slot in PC to insert.

Windows system can control hardware directly. Low latency time.

Suitable for timing critical application.

2) USB to serial port converter.

Support upto 16 serial ports per box.

Need USB connector.

Windows system needs to use USB packet. High latency time.

Suitable for plug and play application.

3) IP Serial Device Server.

Support upto 16 serial ports per box.

Need IP network to link.

Windows system needs to use IP packet. High latency time.

Suitable for multi-host application environment.

4) RAMUXIOP Serial port Expander box.

Support upto 64 serial ports per connection.

Need standard COM connector.

Windows system can use any COM port to expand.

Suitable for plug and play application.

